


Step 2: Detach the bottom of the front gate by slipping the metal guide pin out of the plastic track on both sides.


Step 3: Now remove the gate by dis-engaging the plastic bushings from the grooves in the sides of the front gate.




Remove the plastic bushings (1) and the metal guide pins (2) using a Phillips head screwdriver. Keep the parts in a safe place, as you will need them if you wish to use it as a crib again.







Turn the crib around. Using the Hex Tool, loosen the screw (1) on the side of the crib but **do not remove the screw**. Now remove the screws (2) as shown. Remove the back piece (3) and retain all parts for future use.



5 6

