





“jane”

r o u n d t a b l e



M o d e l # J N 3 5

w w w . b r a t t d e c o r . c o m



Maintenance:

Periodically inspect the table for loose joints, missing parts or sharp edges. Discontinue using the table if any parts are missing or broken.




Cleaning:

If dirty, wipe the table with a damp cloth.


Storage:

Store in a dry place.


PARTS




C
leg connector
1 pc




E
foot
4 pcs



D
foot connector
1 pc




F



H

F 1/4" x 2" machine screws 2



G



I

G 5/16" x 1" machine screws 4

H 4mm hex key 1

I 5mm hex key 1