

## INSTRUCTION SHEET 20 SERIES TWIN/FULL

**STEP 1** MOUNT HEADBOARD BRACKETS TO SHOULDER RIVETS AT END OF SIDE RAILS. SECURE TIGHTLY WITH NUT SHORT BOLT. SEE FIGURE 1.


**STEP 2** SWING CROSS ARMS OUT 90 DEGREES FROM SIDE RAILS TO POSITION SHOWN IN FIGURE 2. **NOTE: NEVER PLACE HANDS NEAR THE PIVOT POINTS.**

**STEP 3** DETERMINE BED WIDTH AND LINE UP THE MATCHING KEYHOLES WITH SHOULDER RIVETS. SEE FIGURE 3.


**STEP 4** INSERT SHOULDER RIVET THROUGH KEYHOLE AS SHOWN IN FIGURE 4. THEN PULL CROSS ARMS OUTWARD AND PUSH LOCKING BRACKET DOWNWARD ONTO SHOULDER RIVET. THIS LOCKS CROSS ARMS IN PLACE AS SHOWN IN FIGURE 5.

**STEP 5** ADD LEG ATTACHMENTS AS SHOWN IN FIGURE 6.


**Figure 1**



**Figure 2**




**Figure 3**



**Figure 4**

SHOULDER RIVET




KEYHOLE

**Figure 5**

LOCKING BRACKET


PUSH



PULL

**Figure 6**

LEG



SOCKET

RUG ROLLER

## AK-ADJUSTAMATIC FOOTBOARD ADAPTOR KIT INSTRUCTION SHEET


### TWIN/FULL BEDDING:

Using hex bolts and tensi-nuts, attach short adaptor rail to siderail and attach footboard bracket to adaptor rail as shown in View 1. Tighten tensi-nuts. Repeat on opposite side.

#### This kit includes:

- 2- Short Adaptor Rails
- 2- Long Adaptor Rails
- 2- Footboard Brackets
- 8- Hex Bolts
- 8- Tensi-Nuts

#### VIEW 1



### QUEEN/KING BEDDING:

Using hex bolts and tensi-nuts, attach long adaptor rail to siderail and attach footboard bracket to adaptor rail as shown in View 2. Tighten tensi-nuts. Repeat on opposite side.

#### VIEW 2

